

## **Straightening your Red Paddle iSUP Fins.**

Occasionally, the fins on your Red Air iSUP will become bent. You should find the the fins can easily be returned straight. It's one of the best features of the Red Air boards - the fins are unbreakable and can take a whole heap of abuse.

Here is a sequence of pictures explaining how to do it.



1. This picture shows a bent fin.



2. Pour hot water from the kettle on to the fin to make the fin flexible.



3. Straighten the fin with your hands and then using sticky tape secure the fin in its upright position.



4. Allow to cool either naturally or by pouring cold water over the fin. You should find your fin is now straight.